TinyTapeout 4/5 Demo Board (preliminary)



Extensive labelling, designed for TT4+ with new MUX, RP2040 on board, accessed via USB.
Project clock from RP2040, external or manual, DIP switches for inputs, 7-segment display (remappable with jumpers) on outputs, full access to 8 in, out and bidirectionals via PMODs, all pins broken out in headers.

Power via +5V USB, or 5V breakout pin. On-board regulation to 3v3 and 1v8. VDDIO is 3v3, including on PMODs.

User Input + Config

Input DIP



Momentary Switches (debounced)

Manual clocking needs to be debounced, but we don't want a big RC filter on the project clock as the RP2040 may want fast edges.
Getting the signal from between R12/R41 makes both of these possible simultaneously.





RP Boot Mode



Power

USB connector

Power and USB2



3V3 LDO



Overpowered LDO allows for external projects/PMODs to be supplied from demo board without issue

1.8V LDO



Changed to smaller SOT-23 LDO for core supply. If using the 2112, can still get up to 600mA which is more than we need and should be safe for external draw.

TT Carrier Power



Note: All this decoupling should be amply handled by the carrier. Would rather DNP than regret.

TT Carrier Logic



SoC $\overline{RST}$ is pulled-up but rising along with power supply glitches the CPU.
Ref design uses MCP1319MT supervisor to handle and add a debounced switch.
A cap does the trick.
TP1 available for all your external reset needs.



The caravel flash is here as a DNP, just in case we want/need it. TT won't normally be using the caravel MCU, but it will still be present and will try to access this flash. Thus, we populate the pull-ups regardless of flash stuff status, and have some stable values on the lines at all times.

NOTE: this is the *caravel* clock. For projects, either feed in via project_clk header pin, clock manually using SW1, or use the RP2040 RP_proj_clk pin.

RP2040 MCU



Possible Comms

Pinout follows non-numerical ordering in order to support various standard communications methods between IC and projects.

In yellow, possible mappings for SPI, I2C and UART, from RP2040 perspective. See in sheet for full mapping.

E.g. if you wanted an SPI controlled periphas part of your TT project, you could configure it such that it uses:
in[0] as select/cs
in[1] for clocking
in[2] for tx/mosi
and
out[3] for rx/miso

Multiplexed signals to increase I/O at low cost.
HK CS low gives access to both
* HK SPI and
* TT MUX control
HK CS high provides access to out port (read from proj. so inputs here). We limit this to out* to avoid the need to maintain state while CS low. The recipe is RP2040 GPIO1:
* LOW -> management (HK SPI/TT MUX)
* HIGH -> interact with TT I/O

Board edge connectors (pinheaders)

I/O is available through standard PMODs or, with judicious placement, as a single 100mil pin header



Indication

LEDs (Power good, GPIO)



7-segment Display



Jumpers allow manual disable/reassign of output -> segments (see footprint)

Misc Support

Mounting holes



Fiducials

Panel-level fids for prod but included for one-offs and testing.



Misc PU/PD.
Project reset is pulled-up via the user switch, project clock PD via its own manual switch.

PMOD

Input PMOD



Bidir PMOD



Output PMOD



PMOD host (female) headers, using digilent's numbering.

SPI Slave



SPI Master/I2C



SPI Bi/UART



PMOD, specialized versions. These PMODs offer an array of options while attempting to keep to standard digilent pinouts. With "SPI Slave", the pmod controls the bus and the project responds. On "SPI Master", the pmod is a peripheral device to the project. The bidir/uart header is flexible.

Psychogenic Technologies

Sheet: /
File: tinytapeout-demo.kicad_sch

Title: TinyTapeout 4/5 Demo Board PRELIM

Size: A3	Date: 2023-11-22	**Rev: 1.0.3**
KiCad E.D.A.	kicad 7.0.9-7.0.9~ubuntu22.04.1	Id: 1/2

RP2040 Basic Support

IOVDD — Logic supply, nominally 3v3.

BOOT_MODE — QSPI_SS: When held low on powerup, flash SS determines boot mode (HIGH == flash boot, LOW == USB device)

USB_VDD supplies USB PHY, nominal 3v3. If IOVDD is 3v3, can share supply.

In fact, in this and many applications, IOVDD, USB_VDD and ADC_AVDD are all powered directly from a single 3v3 supply, with the 1v1 digital core being handle by on-board regulator.

VREG_VOUT: Int core regulator, 1.1V. Can supply DVDD. Place 1uF in/out bypass near pin.

RUN: async reset

J10: Short to hold in reset

J11: Flash program header. Note: should we replace 3v3 with RUN, to be able to reset/hold while updating flash?

WE 830108206909: CFPX-180 model, 10 ppm tol, 20ppm stab, CL 8pF

Rule of thumb: C1, C2 = 2 * CL - 2 * Cstray. Using a stray cap of 5pF, gives Cn = 6pF.

Into: CL = (C1 * C2) / (C1 + C2) + Cstray. These Cn = 6p give CL = 8pF -- just what we need.

Factory test mode: GND

U6 RP2040

Flash

Note: SS pulled-up externally, from bootmode switch

U5 W25Q32JVSS

Quad SPI requires QE bit in status register-2 to be set. In this case, WP becomes IO2 and HOLD becomes IO3.

Supply bypass, place near 1, 10, 22, 33, 42, 49

Supply bypass, near 23, 50

	Function								
GPIO	F1	F2	F3	F4	F5	F6	F7	F8	F9
0	SPI0 RX	UART0 TX	I2C0 SDA	PWM0 A	SIO	PIO0	PIO1		USB OVCUR DET
1	SPI0 CSn	UART0 RX	I2C0 SCL	PWM0 B	SIO	PIO0	PIO1		USB VBUS DET
2	SPI0 SCK	UART0 CTS	I2C1 SDA	PWM1 A	SIO	PIO0	PIO1		USB VBUS EN
3	SPI0 TX	UART0 RTS	I2C1 SCL	PWM1 B	SIO	PIO0	PIO1		USB OVCUR DET
4	SPI0 RX	UART1 TX	I2C0 SDA	PWM2 A	SIO	PIO0	PIO1		USB VBUS DET
5	SPI0 CSn	UART1 RX	I2C0 SCL	PWM2 B	SIO	PIO0	PIO1		USB VBUS EN
6	SPI0 SCK	UART1 CTS	I2C1 SDA	PWM3 A	SIO	PIO0	PIO1		USB OVCUR DET
7	SPI0 TX	UART1 RTS	I2C1 SCL	PWM3 B	SIO	PIO0	PIO1		USB VBUS DET
8	SPI1 RX	UART1 TX	I2C0 SDA	PWM4 A	SIO	PIO0	PIO1		USB VBUS EN
9	SPI1 CSn	UART1 RX	I2C0 SCL	PWM4 B	SIO	PIO0	PIO1		USB OVCUR DET
10	SPI1 SCK	UART1 CTS	I2C1 SDA	PWM5 A	SIO	PIO0	PIO1		USB VBUS DET
11	SPI1 TX	UART1 RTS	I2C1 SCL	PWM5 B	SIO	PIO0	PIO1		USB VBUS EN
12	SPI1 RX	UART0 TX	I2C0 SDA	PWM6 A	SIO	PIO0	PIO1		USB OVCUR DET
13	SPI1 CSn	UART0 RX	I2C0 SCL	PWM6 B	SIO	PIO0	PIO1		USB VBUS DET
14	SPI1 SCK	UART0 CTS	I2C1 SDA	PWM7 A	SIO	PIO0	PIO1		USB VBUS EN
15	SPI1 TX	UART0 RTS	I2C1 SCL	PWM7 B	SIO	PIO0	PIO1		USB OVCUR DET
16	SPI0 RX	UART0 TX	I2C0 SDA	PWM0 A	SIO	PIO0	PIO1		USB VBUS DET
17	SPI0 CSn	UART0 RX	I2C0 SCL	PWM0 B	SIO	PIO0	PIO1		USB VBUS EN
18	SPI0 SCK	UART0 CTS	I2C1 SDA	PWM1 A	SIO	PIO0	PIO1		USB OVCUR DET
19	SPI0 TX	UART0 RTS	I2C1 SCL	PWM1 B	SIO	PIO0	PIO1		USB VBUS DET
20	SPI0 RX	UART1 TX	I2C0 SDA	PWM2 A	SIO	PIO0	PIO1	CLOCK GPIN0	USB VBUS EN
21	SPI0 CSn	UART1 RX	I2C0 SCL	PWM2 B	SIO	PIO0	PIO1	CLOCK GPOUT0	USB OVCUR DET
22	SPI0 SCK	UART1 CTS	I2C1 SDA	PWM3 A	SIO	PIO0	PIO1	CLOCK GPIN1	USB VBUS DET
23	SPI0 TX	UART1 RTS	I2C1 SCL	PWM3 B	SIO	PIO0	PIO1	CLOCK GPOUT1	USB VBUS EN
24	SPI1 RX	UART1 TX	I2C0 SDA	PWM4 A	SIO	PIO0	PIO1	CLOCK GPOUT2	USB OVCUR DET
25	SPI1 CSn	UART1 RX	I2C0 SCL	PWM4 B	SIO	PIO0	PIO1	CLOCK GPOUT3	USB VBUS DET
26	SPI1 SCK	UART1 CTS	I2C1 SDA	PWM5 A	SIO	PIO0	PIO1		USB VBUS EN
27	SPI1 TX	UART1 RTS	I2C1 SCL	PWM5 B	SIO	PIO0	PIO1		USB OVCUR DET
28	SPI1 RX	UART0 TX	I2C0 SDA	PWM6 A	SIO	PIO0	PIO1		USB VBUS DET
29	SPI1 CSn	UART0 RX	I2C0 SCL	PWM6 B	SIO	PIO0	PIO1		USB VBUS EN

Psychogenic Technologies

Sheet: /RP2040/

File: rp2040.kicad_sch

Title: RP2040 Basic Support

Size: A4	Date: 2023-11-22	**Rev: 1.0.3**
KiCad E.D.A. kicad 7.0.9-7.0.9~ubuntu22.04.1		Id: 2/2


TinyTapeout 4+
Demoboard Alpha
(C) 2023 Pat Deegan
v0.9
tinytapeout.com
AISLER
zerotoasic
course.com
psychogenic
OSHW
ES0000??
1.8V 3.3V 5V
POWER GOOD
GPIO
SPI BI/UART
SPI SLV
SPI MSTR
INPUT
CLOCK
RESET
BIDIR
OUTPUT
SW1
SW2
SW3
SW4
U1
U4
U6
J7
J12
J14
J15
in3 in2 in1 in0
bi3 bi2 bi1 bi0
ot3 ot2 ot1 ot0
CLK RST
5V GND



4-layer, Aisler stackup
0.3mm drill min
>6mil traces
basic controlled Z

Psychogenic Technologies

Sheet:
File: tinytapeout-demo.kicad_pcb

Title: TinyTapeout 4+ Demoboard

Size: User	Date: 2023-11-22	**Rev: 0.9.2**
KiCad E.D.A. kicad 7.0.9-7.0.9-ubuntu22.04.1		Id: 1/1